






# Caster Guide



## - For living -English Edition





HAMMER CASTER products are used everywhere. It's seamlessly blended into your life.

Hammer Caster has started their own caster production when casters are not even commonly spread in Japan. We have been supporting the lives of our customers in every corner of the world for a century.









### Basic Specifications

Swivel caster



Swivel caster is the most common type that is also known as "Free type". It can move in any direction by pushing and pulling at your will.

Swivel caster with Stopper



Stopper type can lock the wheel by side-brake handle. Some caster has "Total Lock" stopper that locks swivel and brake wheel at once.

Fixed caster with Stopper

Fixed caster



Fixed caster only goes straight on fixed direction. Commonly installed in combination with the swivel casters for carts and hand trucks.

3



Fixed caster goes straight only in a certain direction. Stopper type can lock the wheel by side-brake handle.

## • Fitting types & Installation ideas

Plate type





For hand truck, carry, DIY making, etc...

For wheel chairs, shopping carts, signboards, etc...



Plain stem type




With optional socket and bracket, attachable to wooden products.



For wooden furniture, pipe racks, etc...









Easy fitting by fastening the bolt with a spanner.





### Expander stem type

With expanding plug stem, attachable to pipe tubes. Easy fitting by fastening the bolt with a spanner. Available in 3 different plug types, covering 17 kinds of pipe tubes.



4)

For lightweight pipe racks used in kitchens and hospitals, etc...



## •Wheel Material Characteristics




#### **Rubber wheel**

With the low surface hardness the elastic property meets the requirement of cushion, which enables a stable travel on uneven grounds.

#### **Urethane wheel**

**Elastomer wheel** 



#### Nylon wheel



Nylon wheel is light, hard, and excellently resistant against heat, chemical, corrosion and wear. It may generate running noise when attached to a cart, but it can move things with light force.



Elastomer wheel has elasticity similar to rubber and is excellently resistant against heat, weather and chemicals.

### About Elastomer

Elastomer wheel enables to run quietly and softly without leaving scratches or marks on the floor. It is used in a wide range of places such as office equipment, indoor transporters, lightweight racks, and DIY making.



Elastomer is a polymer material that combines the superior properties of elastic rubber and plastic, which is easy to mold and highly recyclable, and is expected to play an active role in a wide range of industrial fields.

### Maintenances

## Please make sure to do periodic checking, maintenance and replacement for a long service life and product safety.

Please check slacks on fastening bolts on mounting part and wheel axle part, and make sure to fasten when necessary.

•Please lubricate swivel part and wheel axle part, and make sure to remove dusts in ball laces.

In general, the physical properties of resin products may deteriorate due to use conditions and aging changes. Please replace resin products as necessary.


•When you found cracks and/or backlashes to caster parts, please replace them with the relevantly new ones.

Please check the brake performance periodically. If there is any abnormality in braking performance or operation, replace it with a new one.



Do not lade over the load capacity.





 Do not leave casters braking on slopes.

• Stopper device is considered to be loosened unknowingly or to be released abruptly by external shocks.






 Do not fasten to an undue degree as the stem strains.

 Do not push forcibly to move locked casters.



# Office

"Quiet" casters that minimizes the noise emitted from running in office.





Stylish casters designed for inteiror and furniture. Available with easy fitting models for DIY making.



■Casters designed for furniture.



Casters with simple and easy attachment carry out various things, not only for furniture.







155-R 50mm





Please consult our sales office for details.


Use : DIY/ Furniture





# Shopping Mall

Light weight touch to sparkling move. Smooth casters are trotting in shopping malls and markets.



■Use : Shopping cart





420REA-UBB 100mm

■Use : Shopping cart



12

# Medical



#### Twin-wheel casters enhances travel stability.





13

750K-FA1 100mm (Gray)

#### ■Use : Medical bed / Nurse cart



Luxuary and robust casters with chromium coating.



Swivel Total lock



920MA-RB 100mm

915M-KUB 100mm

#### Use : Stretcher / Medical wagon / Medical equipment



# Restaurant



Luxurious presence of chromium coating attachable with various fitting types.



415 2EN-UR 100mm



420ER-PR 100mm

■Use : Hand truck/ Catering truck



All stainless steel casters are excellent resistant against water and corrosion.





315S-N 100mm

15



Wheel color can be arranged in gray and black.



Please consult our sales office for details.

■Use : Stainless cart/ Stainless workbench





# Sports



Chromium coated casters to satisfy design and lightness.



916EA-PR 75mm



415EA-UR 100mm

■Use : Ball stocker



Casters with high load performance, smooth turning and toughness.



#### ■Use : Mobile safety net fence





# Terminal

Silent, functional and robust. Casters at terminal require high load performance, smooth turning and durability.








# NETWORK

21



### Manufacturing Factory

Headquarters factory 4-7-35, Nishi-Iwata, Higashi-Osaka, Osaka 578-0947 Japan Hirakata factory Shodaitajika, Hirakata, Osaka 573-1132 Japan

Tokyo Branch Osaka Branch

### Please feel free to ask for any caster consultancy.

E-mail: info@hammer-caster.co.jp w e b : www.hammer-caster.com

### Click and follow our official SNS accounts.



www.facebook.com/hammercasterofficial/



### Hammer Caster Sales Co.Ltd. (as Sales company)

6-5-4, Sinbashi, Minato-ku, Tokyo 105-0004 Japan

10-35, Shinjyo-Nishi, Higashi-Osaka, Osaka 578-0964 Japan

www.instagram.com/hammer\_caster\_official/

